

#05007

LA VESQUE

6/13/2005

4RSPH W/ 65" - TANK

**PLUG 3**

**PIN #**

**[LG 16]**

1	18	RED	CB6 TO WIPER	
2	12	RED	CB6 TO RADIO	
3	705	PURPLE	OIL PRESSURE SENSO TO GAUGE	ORG/RED 14
4	20	BLACK	GROUND	
5	503	BROWN	LIGHT SWITCH ROAD POSITION TO RELAY #5-86	
6	22	RED	CB8 TO DOME LIGHT/PANEL/LITE SWT/RADIO MEM ( ST87 HOT )	
*7	507	BROWN	CAB FIELD LIGHT RELAY TO CAB FIELD LIGHTS #4-30	
8	572	BROWN	WORK LIGHT SWITCH TO LEFT WORK LIGHTS RELAYS	
9	924	ORANGE	OIL PRESSURE SENSOR TO LIGHT	ORG/BLUE 19
*10	526	BROWN	CAB ROAD LIGHT RELAY TO CAB LIGHTS #5-30	
11	652	BLUE	FUEL TANK SENDER TO GAUGE	WHITE 58
12	653	BLUE	COOLANT TEMP. SENSOR TO LIGHT	ORG/BLK 9
13	617	GREEN	COOLANT TEMP. SENDER TO GAUGE	ORANGE 4
14	504	BROWN	CAB FIELD LIGHT POSITION TO RELAY #4-86	
*15	156	BLACK	CB15 TO AUXILLARY OUTLET BOX 12 AWG	
16	437	GRN.	PRIM. CIRCUIT TEMP. GAUGE TO GRD. AT SENDER	

#05007

LA VESQUE

6/13/2005

4RSPH W/ 65" - TANK

**PLUG 3**

**PIN #**

**[LG 16]**

1	18	RED	CB6 TO WIPER	
2	12	RED	CB6 TO RADIO	
3	705	PURPLE	OIL PRESSURE SENSO TO GAUGE	ORG/RED 14
4	20	BLACK	GROUND	
5	503	BROWN	LIGHT SWITCH ROAD POSITION TO RELAY #5-86	
6	22	RED	CB8 TO DOME LIGHT/PANEL/LITE SWT/RADIO MEM ( ST87 HOT )	
*7	507	BROWN	CAB FIELD LIGHT RELAY TO CAB FIELD LIGHTS #4-30	
8	572	BROWN	WORK LIGHT SWITCH TO LEFT WORK LIGHTS RELAYS	
9	924	ORANGE	OIL PRESSURE SENSOR TO LIGHT	ORG/BLUE 19
*10	526	BROWN	CAB ROAD LIGHT RELAY TO CAB LIGHTS #5-30	
11	652	BLUE	FUEL TANK SENDER TO GAUGE	WHITE 58
12	653	BLUE	COOLANT TEMP. SENSOR TO LIGHT	ORG/BLK 9
13	617	GREEN	COOLANT TEMP. SENDER TO GAUGE	ORANGE 4
14	504	BROWN	CAB FIELD LIGHT POSITION TO RELAY #4-86	
*15	156	BLACK	CB15 TO AUXILLARY OUTLET BOX 12 AWG	
16	437	GRN.	PRIM. CIRCUIT TEMP. GAUGE TO GRD. AT SENDER	