

#04005

6RSPPH

KENNY FARMS

12/23/2004

PLUG 3

PIN #

[LG 16]

1	18	RED	CB6 TO WIPER
2	12	RED	CB6 TO RADIO
3	✓ 752	YELLOW	HYDRAULIC OIL TANK TEMPERATURE SENDER
4	20	BLACK	GROUND
5	503	BROWN	LIGHT SWITCH ROAD POSITION TO RELAY #5-86
6	22	RED	CB8 TO DOME LIGHT/PANEL/LITE SWT/RADIO MEM (ST87 HOT)
*7	507	BROWN	CAB FIELD LIGHT RELAY TO CAB FIELD LIGHTS #4-30
8	572	BROWN	WORK LIGHT SWITCH TO LEFT WORK LIGHTS RELAYS
9	✓ 753	YELLOW	HYD. OIL TANK TEMP. GAUGE TO GRD. AT SENDER
*10	526	BROWN	CAB ROAD LIGHT RELAY TO CAB LIGHTS #5-30
11	✓ 652	BLUE	FUEL TANK SENDER TO GAUGE
12	✓ 425	GREEN	PRIMARY CIRCUIT TEMP. SENDER
13			
14	504	BROWN	CAB FIELD LIGHT POSITION TO RELAY #4-86
*15	156	BLACK	CB15 TO AUXILLARY OUTLET BOX 12 AWG
16	✓ 437	GRN.	PRIM. CIRCUIT TEMP. GAUGE TO GRD. AT SENDER

#04005

6RSPPH

KENNY FARMS

12/23/2004

PLUG 3

PIN #

[LG 16]

1	18	RED	CB6 TO WIPER
2	12	RED	CB6 TO RADIO
3	✓ 752	YELLOW	HYDRAULIC OIL TANK TEMPERATURE SENDER
4	20	BLACK	GROUND
5	503	BROWN	LIGHT SWITCH ROAD POSITION TO RELAY #5-86
6	22	RED	CB8 TO DOME LIGHT/PANEL/LITE SWT/RADIO MEM (ST87 HOT)
*7	507	BROWN	CAB FIELD LIGHT RELAY TO CAB FIELD LIGHTS #4-30
8	572	BROWN	WORK LIGHT SWITCH TO LEFT WORK LIGHTS RELAYS
9	✓ 753	YELLOW	HYD. OIL TANK TEMP. GAUGE TO GRD. AT SENDER
*10	526	BROWN	CAB ROAD LIGHT RELAY TO CAB LIGHTS #5-30
11	✓ 652	BLUE	FUEL TANK SENDER TO GAUGE
12	✓ 425	GREEN	PRIMARY CIRCUIT TEMP. SENDER
13			
14	504	BROWN	CAB FIELD LIGHT POSITION TO RELAY #4-86
*15	156	BLACK	CB15 TO AUXILLARY OUTLET BOX 12 AWG
16	✓ 437	GRN.	PRIM. CIRCUIT TEMP. GAUGE TO GRD. AT SENDER