

COLUMN PLUG

#04005

6RSPPH

KENNY FARMS

12/23/2004

PLUG 5

PIN #

COLUMN PLUG

1	11	RED	ST 87 HOT SIDE TERMINAL	
1	12	RED	KEY SWITCH " ACC " POSITION	
3	13	RED	ST 87 IGINATION TERMINALS	
4	502	BROWN	POWER FROM TURN STAT	502 TO 507
5	104	WHITE	CLUTCH SWITCH N.C. TO RELAY	
14	059	BLACK	TO CLUTCH SWITCH N.O. POSITON TO 15 (5)	
15	0015	RED	TO SMX SWITCH - "COM" / N.O. ON SMX RED 15 TO SV4 SOLENOID	
18	522	BROWN	RIGHT TURN SIGNAL - BROWN 54 ON MACHINE	512 TO 522
20	523	BROWN	LEFT TURN SIGNAL - YELLOW 53 ON MACHINE	513 TO 523

RED 11A

—
RED 022

RED 13 [RED 012

RED 412] RED 12

WHITE 104

—
RED 422

(RED 422 FROM POWER VIEW TO START RELAY TO ECU)

RED 13A [RED 442

] RED 12A

—
ORANGE 924

KEY SWITCH KEYING
POWER VIEW KEY SWITCH KEYING

COLUMN PLUG

#04005

6RSPPH

KENNY FARMS

12/23/2004

PLUG 5

PIN #

COLUMN PLUG

1	11	RED	ST 87 HOT SIDE TERMINAL	
1	12	RED	KEY SWITCH " ACC " POSITION	
3	13	RED	ST 87 IGINATION TERMINALS	
4	502	BROWN	POWER FROM TURN STAT	502 TO 507
5	104	WHITE	CLUTCH SWITCH N.C. TO RELAY	
14	059	BLACK	TO CLUTCH SWITCH N.O. POSITON TO 15 (5)	
15	0015	RED	TO SMX SWITCH - "COM" / N.O. ON SMX RED 15 TO SV4 SOLENOID	
18	522	BROWN	RIGHT TURN SIGNAL - BROWN 54 ON MACHINE	512 TO 522
20	523	BROWN	LEFT TURN SIGNAL - YELLOW 53 ON MACHINE	513 TO 523

RED 11A

—
RED 022

RED 13 [RED 012

RED 412] RED 12

WHITE 104

—
RED 422

(RED 422 FROM POWER VIEW TO START RELAY TO ECU)

RED 13A [RED 442

] RED 12A

—
ORANGE 924

KEY SWITCH KEYING
POWER VIEW KEY SWITCH KEYING