

**COLUMN PLUG**

#05006

6RSPPH

T&R FARMS

3/9/2005

**PLUG 5**

| PIN # |               | COLUMN PLUG |       |  |                   |
|-------|---------------|-------------|-------|--|-------------------|
| 1     | 11            | P           | RED   | ST 87 HOT SIDE TERMINAL                                    | 12' 6"            |
| 1     | <del>12</del> |             | RED   | KEY SWITCH "ACC" POSITION                                  |                   |
| 3     | 13            | P           | RED   | ST 87 IGINATION TERMINALS                                  | 12' 6"            |
| 4     | 502           | P           | BROWN | POWER FROM TURN STAT                                       | 12' 6" 502 TO 507 |
| 5     | 104           | P           | WHITE | CLUTCH SWITCH N.C. TO RELAY                                | 12' 6"            |
| 14    | 059           | Z           | BLACK | TO CLUTCH SWITCH N.O. POSITON TO 15 ( 5 )                  | 14'               |
| ✓15   | 0015          |             | RED   | TO SMX SWITCH - "COM" / N.O. ON SMX RED 15 TO SV4 SOLENOID |                   |
| 18    | 522           | Z           | BROWN | RIGHT TURN SIGNAL - BROWN 54 ON MACHINE                    | 14' 512 TO 522    |
| 20    | 523           | Z           | BROWN | LEFT TURN SIGNAL - YELLOW 53 ON MACHINE                    | 14' 513 TO 523    |

RED 11A

—  
RED 022

RED 13 [ RED 012

RED 412 ] RED 12

WHITE 104

—  
RED 422

( RED 422 FROM POWER VIEW TO START RELAY TO ECU )

RED 13A [ RED 442

] RED 12A

—  
ORANGE 924

KEY SWITCH KEYING

POWER VIEW KEY SWITCH KEYING

**COLUMN PLUG**

#05006

6RSPPH

T&R FARMS

3/9/2005

**PLUG 5**

| PIN # |               | COLUMN PLUG |       |  |                   |
|-------|---------------|-------------|-------|--|-------------------|
| 1     | 11            | P           | RED   | ST 87 HOT SIDE TERMINAL                                    | 12' 6"            |
| 1     | <del>12</del> |             | RED   | KEY SWITCH "ACC" POSITION                                  |                   |
| 3     | 13            | P           | RED   | ST 87 IGINATION TERMINALS                                  | 12' 6"            |
| 4     | 502           | P           | BROWN | POWER FROM TURN STAT                                       | 12' 6" 502 TO 507 |
| 5     | 104           | P           | WHITE | CLUTCH SWITCH N.C. TO RELAY                                | 12' 6"            |
| 14    | 059           | Z           | BLACK | TO CLUTCH SWITCH N.O. POSITON TO 15 ( 5 )                  | 14'               |
| ✓15   | 0015          |             | RED   | TO SMX SWITCH - "COM" / N.O. ON SMX RED 15 TO SV4 SOLENOID |                   |
| 18    | 522           | Z           | BROWN | RIGHT TURN SIGNAL - BROWN 54 ON MACHINE                    | 14' 512 TO 522    |
| 20    | 523           | Z           | BROWN | LEFT TURN SIGNAL - YELLOW 53 ON MACHINE                    | 14' 513 TO 523    |

RED 11A

—  
RED 022

RED 13 [ RED 012

RED 412 ] RED 12

WHITE 104

—  
RED 422

( RED 422 FROM POWER VIEW TO START RELAY TO ECU )

RED 13A [ RED 442

] RED 12A

—  
ORANGE 924

KEY SWITCH KEYING

POWER VIEW KEY SWITCH KEYING